

MORTUARY CHAMBER 2 BODIES - 1 DOOR

Cod. CAM020201

Characteristics



Disclaimer:
Images are purely
indicative. The features
and the accessories of the
products may differ
according to model and
application.

Temperature range	+2 / +8 °C
Capacity	2 bodies on 2 levels
External Dimensions (WxDxH)	cm 121x226x234 <i>External dimensions without monoblock unit: cm 121x226x196</i>
Structure and Insulation	White coated steel inside and outside; insulation polyurethane thickness 80 mm
Door	n.1 door
Key Lock	
Light	
Internal equipment	n.2 steel body trays
Controller	Digital electronic thermostat
Alarms	Acoustic and Visual for temperature deviations and failures
Refrigeration Type	Ventilated
Defrost	Automatic with automatic evaporation of the condensate water

Technical data

Details	<ul style="list-style-type: none"> • Refrigerant type: R452A, CFC free • Mains Voltage 220V/1/50Hz • HP 3/4 E ;kW 0,5 • Refrigerating capacity: 1335 W • Ambient Temperature: +10/+38 °C; Humidity 60% • Connector: Schuko
In accordance with	2006/42/CE, 2014/30/CE, 2014/35/CE and following modifications
Package	Chamber to be installed on site, packed in cellophane on pallet, monoblock in strong cardboard on wooden pallet

Internal covering in stainless steel

External covering in stainless steel

DMLP UNIT

External module with DMLP DIGITAL MONITOR:
Monitor/alarm/recording system with rechargeable battery
- Temperatures and alarms recorder on removable Secure Digital (SD Back-Up memory): it can store 5 years data, recording temperature and alarms every minute.
The SD card can be connected to any PC: a software (Capture) is included, so that you can download, save and print all data from your PC
- Battery backup: ensures alarms and recording of temperatures even in case of power failure. The battery system lasts about 12 hours.
- Dry contact for remote connection + RS485 port

DMLP PRINTER

Additional body tray

Hydraulic trolley cm 30 -165

Hydraulic trolley with 12V electrical adjustment cm 30 -165

60 Hz Frequency

FIOCCHETTI SCIENTIFIC S.R.L.

Headquarter: Via Panagulis, 48 - 42045 Luzzara (RE) Italy
VAT No. IT00934960352

Phone +39 0522 976232 - Fax +39 0522 976028

www.fiocchetti.com - Email: info@fiocchetti.it - Pec: fiocchetti@pec.it